


BSA33R-E5AA


(Type 1 RET Configuration Only)

Top of antenna Viewed from rear




RET placement as view from rear of antenna

Top of antenna



RIGHT
1695-2690
A1
Ports 3 & 4



LEFT
1695-2690
A1
Ports 1 & 2

Array	Ports	Freq (MHz)	Beam	Ports controlled by common RET
A1	1, 2	1695-2690	Left	1, 2
A1	3, 4	1695-2690	Right	3, 4