


BSA33V-E5AA (VET Configuration Only)

Top of antenna Viewed from rear



VET placement as view from rear of antenna

Top of antenna



RIGHT
1695-2690
A1
Ports 3 & 4



LEFT
1695-2690
A1
Ports 1 & 2

Array	Ports	Freq (MHz)	Beam	Ports controlled by VET knob
A1	1, 2	1695-2690	Left	1, 2
A1	3, 4	1695-2690	Right	3, 4