


# HBSA33R-KE6BA

## (Type 17 RET Configuration Only)

**Element arrays as viewed  
from rear of antenna**




**RET placement  
as viewed from rear  
of antenna**

Top of antenna



MM.1



MM.2 MM.3

Array	Ports	Freq (MHz)	Ports controlled by common RET	AISG RET UID
<b>R1</b>	<b>1, 2</b>	<b>698-960</b>	<b>1, 2</b>	ClxxxxxxMM.1
<b>Y1</b>	<b>3, 4</b>	<b>1695-2690</b>	<b>3, 4, 5, 6</b>	ClxxxxxxMM.2
<b>Y2</b>	<b>5, 6</b>	<b>1695-2690</b>		
<b>Y3</b>	<b>7, 8</b>	<b>1695-2690</b>	<b>7, 8, 9, 10</b>	ClxxxxxxMM.3
<b>Y4</b>	<b>9, 10</b>	<b>1695-2690</b>		